

System Assembly Instructions



pH Neutralizer components

- Fiberglass tank for material
- Riser Tube
- Control Valve
- By-pass Valve
- Gravel
- Calcite & Corosex
- Funnel

1



- Place riser tube on the mineral tank
- Flush to the top

2



- Place stopper on top of riser tube
- Add Funnel

3



- Pour the gravel into the tank

4



5

- Mix Calcite and Corosex in a bucket and blend them into the right proportion



6

- Pour the blended media into the tank leaving 14" from the top



7

- Remove the stopper



8

- Screw on the Control head; Slip over the riser tube



9

- Put the system in By-pass



10

- Secure by-pass Valve to the control head



11

- Install the Backwash line