

Fleck 5600 SXT Settings for Softeners & BackWash Filter

To Enter Master Program Mode:

1. Set time to 12:01 PM by pressing and holding UP or DOWN arrows appropriately
2. Press CYCLE Button to accept time settings
3. Press and Hold UP and DOWN arrows for 3-5 seconds until screen reads DF GAL
4. Edit parameter value using UP/DOWN arrows
5. Navigate through Parameters by pressing the CYCLE Button

	Abbreviation	Parameter	Softener		BW Filters	OCS
			5600 & 2510	9100		
Standard Settings	DF	Display Format	GAL		GAL	GAL
	VT	Valve Type	dF1b	dF1b	FLtr	dF1b
	CT	Control Type	Fd	FI	tc	tc
	NT	Number of Tanks	1	2	1	1
	C	Unit Capacity <i>(The capacity per tank)</i>	9x48: 32 10x54: 48 12x52: 64		∅	∅
	H	Feedwater Hardness	Hardness of Water (Determined by test)		∅	∅
	RS	Reserve Selection	SF		∅	∅
	SF	Safety Factor	15	10	∅	∅
	DO	Day Override	14		3	2 or 3
	RT	Regen Time	2:00 AM default		12:00	12:30
	BW	Backwash	10 min default		10	14
	BD	Brine Draw	60 min default		∅	10-20
	RR	Rapid Rinse	10 min default		10	1
	BF	Brine Fill	Please Set: 10 min to 9x48 15 min to 10x54 19 min to 12x52 <i>(Capacity per tank)</i>		∅	Off
	FM	Flow Meter Type	0.7 default		∅	∅